

# 20CYS114 - Cyber Security Essentials Labs Lab 1 - Computer Network Fundamentals

Task 1: Find the status of your Active network.

Steps followed: Go to Control Panel-> Network and Internet Settings -> View Network Status and Tasks -> Change Adapter Settings -> Right Click on your adapter (Either ethernet or Wi-Fi) -> Click status -> Click Details.

## Output:





## **Observations:**

- The network connection window gives the details about physical address, IPv4 and IPv6 address, lease obtained and lease expired, its network type and its availability in the current windows system.
- ➤ The physical address, also known as the link address, is the address of a node as defined by its LAN or WAN.
- ➤ When you enable DHCP, it means you allow DHCP server to automatically assign IP address for your device, so you don't need to manually type the IP address and DNS for your computer from time to time.

- ➤ The IPv4 address is a 32-bit number that uniquely identifies a network interface on a machine.
- ➤ IPv6 (Internet Protocol version 6) is the sixth revision to the Internet Protocol and the successor to IPv4. It functions similarly to IPv4 in that it provides the unique IP addresses necessary for Internetenabled devices to communicate.
- Subnet masks (IPv4) and prefixes (IPv6) identify the range of IP addresses that make up a subnet, or group of IP addresses on the same network.
- The lease obtained is simply stating when your computer received it's IP address. The lease expiration is when your computer will renew it's IP address with the DHCP server.
- ➤ A default gateway is the node in a computer network using the Internet protocol suite that serves as the forwarding host to other networks when no other route specification matches the destination IP address of a packet.
- ➤ Domain Name System is the Internet's system for converting alphabetic names into numeric IP addresses.

Task 2: Identifying current TCP/IP network configuration values using IPCONFIG

```
Administrator: Command Prompt
Microsoft Windows [Version 10.0.22000.493]
(c) Microsoft Corporation. All rights reserved.
:\WINDOWS\system32>ipconfig
Windows IP Configuration
Ethernet adapter Ethernet:
  Media State . . . . . . . . . : Media disconnected Connection-specific DNS Suffix . :
Ethernet adapter VirtualBox Host-Only Network:
  Connection-specific DNS Suffix .:
  Link-local IPv6 Address . . . . : fe80::3d9e:6229:145f:5960%18
  IPv4 Address. . . . . . . . . : 192.168.56.1
  Default Gateway . . . . . . . :
Wireless LAN adapter Local Area Connection* 1:
  Media State . . . . . . . . : Media disconnected Connection-specific DNS Suffix . :
Wireless LAN adapter Local Area Connection* 2:
  Media State . . . . . . . . . : Media disconnected Connection-specific DNS Suffix . :
Ethernet adapter VMware Network Adapter VMnet1:
  Connection-specific DNS Suffix .:
  Link-local IPv6 Address . . . . : fe80::e5d9:d2d6:a04:2466%7
  IPv4 Address. . . . . . . . . : 192.168.42.1
  Subnet Mask . . . . . . . . . : 255.255.255.0
  Default Gateway . . . . . . . :
Ethernet adapter VMware Network Adapter VMnet8:
  Connection-specific DNS Suffix .:
  Link-local IPv6 Address . . . . : fe80::e5a7:2c9a:258b:d3d6%17
  IPv4 Address. . . . . . . . . : 192.168.157.1
  Subnet Mask . . . . . . . . . : 255.255.255.0
  Default Gateway . . . . . . . :
Wireless LAN adapter Wi-Fi:
```

This command (ipconfig) allows you to get the IP address information of a Windows computer. It also allows some control over active TCP/IP connections.

## a. Ipconfig/all

```
Administrator: Command Prompt
C:\WINDOWS\system32>Ipconfig/all
Windows IP Configuration
    Ethernet adapter Ethernet:
   Connection-specific DNS Suffix .:

Description . . . .
    Description . . . . . . . . : Realtek Gaming GbE Family Controller
    Physical Address. . . . . . . : 04-42-1A-88-DA-D6
    DHCP Enabled. . . . . . . . : Yes
    Autoconfiguration Enabled . . . . : Yes
Ethernet adapter VirtualBox Host-Only Network:
    Connection-specific DNS Suffix .:
   Description . . . . : VirtualBox Host-Only Ethernet Adapter Physical Address . . . : 0A-00-27-00-00-12

        Physical Address.
        : 0A-00-27-00-00-12

        DHCP Enabled.
        : No

        Autoconfiguration Enabled
        : Yes

        Link-local IPv6 Address.
        : fe80::3d9e:6229:145f:5960%18(Preferred)

        IPv4 Address.
        : 192.168.56.1(Preferred)

        Subnet Mask
        : 255.255.255.0

        Default Gateway
        :

        DHCPv6 IAID
        : 722075687

        DHCPv6 Client DUID
        : 00-01-00-01-28-DE-92-AC-04-42-1A-88-DA-D6

        NetBIOS over Tcpip
        : Enabled

Wireless LAN adapter Local Area Connection* 1:
    Connection-specific DNS Suffix . :
Description . .
    Description . . . . . : Microsoft Wi-Fi Direct Virtual Adapter Physical Address . . . . . : 08-6A-C5-56-C2-BA
    DHCP Enabled. . . . . . . . : Yes Autoconfiguration Enabled . . . : Yes
Wireless LAN adapter Local Area Connection* 2:
   Media State . . . . . . . . : : : Connection-specific DNS Suffix . :
    Media State . .
                                                  . . : Media disconnected
    Description . . . . . . . : Microsoft Wi-Fi Direct Virtual Adapter #2 Physical Address . . . . . . : 0A-6A-C5-56-C2-B9
```

The ipconfig /all command displays all configuration information for each adapter bound to TCP/IP.

# b. Ipconfig/flushdns

```
Administrator.Command Prompt

C:\WINDOWS\system32>Ipconfig/flushdns

Windows IP Configuration

Successfully flushed the DNS Resolver Cache.

C:\WINDOWS\system32>
```

The ipconfig /flushdns command clears the cache of name to IP entries and reloads them from the connected DNS server.

## c. Ipconfig/?

```
Administrator: Command Promp
  :\WINDOWS\system32>Ipconfig/?
 JSAGE:
      ipconfig [/allcompartments] [/? | /all |
                                                 [/f | /411 |
/renew [adapter] | /release [adapter] |
/renew6 [adapter] | /release6 [adapter] |
/flushdns | /displaydns | /registerdns |
/showclassid adapter |
/setclassid adapter [classid] |
                                                  /showclassid6 adapter |
/setclassid6 adapter [classid] ]
      adapter
                                   (wildcard characters * and ? allowed, see examples)
      Options:
                                   Display this help message
           /all
                                   Display full configuration information.
Release the IPv4 address for the specified adapter.
Release the IPv6 address for the specified adapter.
           /release
           /release6
                                   Renew the IPv4 address for the specified adapter.
Renew the IPv6 address for the specified adapter.
           /renew
           /renew6
           /flushdns
                                    Purges the DNS Resolver cache.
           /registerdns
                                    Refreshes all DHCP leases and re-registers DNS names
                                   Displays all the dhcp class Id.

Modifies the dhcp class Id.

Displays all the IPv6 DHCP class IDs allowed for adapter.
           /displaydns
           /showclassid
           /setclassid
           /showclassid6
                                    Modifies the IPv6 DHCP class id.
The default is to display only the IP address, subnet mask and default gateway for each adapter bound to TCP/IP.
For Release and Renew, if no adapter name is specified, then the IP address
leases for all adapters bound to TCP/IP will be released or renewed.
 or Setclassid and Setclassid6, if no ClassId is specified, then the ClassId is removed.
 xamples:
      > ipconfig
                                                       ... Show information
      > ipconfig /all
                                                       ... Show detailed information
      > ipconfig /renew
> ipconfig /renew EL*
                                                       ... renew all adapters
                                                       ... renew any connection that has its name starting with EL
                                                       ... release all matching connections,
eg. "Wired Ethernet Connection 1" or
       > ipconfig /release *Con*
```

The ipconfig/? command shows the small description of the ipconfig command with all of it's arguments.

## d. Ipconfig/showclassid adapter

```
compartments

C:\WINDOWS\system32>Ipconfig/showclassid adapter

Windows IP Configuration

The operation failed as no adapter is in the state permissible for this operation.

C:\WINDOWS\system32>
```

The ipconfig/showclassid adapter command displays the DHCP class IDs allowed for the current adapter, as my current adapter is not state permissible this action has failed.

Task 3: Test the reachability of a host on an Internet using PING

#### a. Ping www.google.com

```
C:\WINDOWS\system32>Ping www.google.com

Pinging www.google.com [2404:6800:4007:813::2004] with 32 bytes of data:
Request timed out.
Reply from 2404:6800:4007:813::2004: time=17ms
Reply from 2404:6800:4007:813::2004: time=20ms
Reply from 2404:6800:4007:813::2004: time=19ms

Ping statistics for 2404:6800:4007:813::2004:
    Packets: Sent = 4, Received = 3, Lost = 1 (25% loss),
Approximate round trip times in milli-seconds:
    Minimum = 17ms, Maximum = 20ms, Average = 18ms

C:\WINDOWS\system32>
```

The ping command is used to test if you can reach your target and how much time it will take to do it. When you use this command, you will send few echo requests, usually 4. Then you will receive a result for each of them, that indicates if they were successful, how much data was received, the time it took for the response and TTL (Time to live).

#### b. Ping 127.0.0.1

```
C:\WINDOWS\system32>Ping 127.0.0.1

Pinging 127.0.0.1 with 32 bytes of data:
Reply from 127.0.0.1: bytes=32 time<1ms TTL=128

Ping statistics for 127.0.0.1:

Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:

Minimum = 0ms, Maximum = 0ms, Average = 0ms

C:\WINDOWS\system32>
```

The ping command pings the given 127.0.0.1 and sends packets of data to which we get replies from the machine with that IP address, with the important information about the packet loss and the minimum and maximum time taken by that packet.

c. Ping www.google.com -n 8

```
C:\WINDOWS\system32>Ping www.google.com -n 8

Pinging www.google.com [2404:6800:4009:82b::2004] with 32 bytes of data:
Request timed out.
Reply from 2404:6800:4009:82b::2004: time=39ms
Reply from 2404:6800:4009:82b::2004: time=39ms
Reply from 2404:6800:4009:82b::2004: time=39ms
Reply from 2404:6800:4009:82b::2004: time=39ms
Reply from 2404:6800:4009:82b::2004: time=38ms
Reply from 2404:6800:4009:82b::2004: time=38ms
Reply from 2404:6800:4009:82b::2004: time=37ms
Reply from 2404:6800:4009:82b::2004: time=46ms

Ping statistics for 2404:6800:4009:82b::2004:
    Packets: Sent = 8, Received = 7, Lost = 1 (12% loss),
Approximate round trip times in milli-seconds:
    Minimum = 37ms, Maximum = 46ms, Average = 39ms

C:\WINDOWS\system32>
```

This ping command differs from the first subdivision (a. Ping www.google.com) as now the number of packets sent are controlled by the -n parameter, which here is 8 packets

Task 4: Diagnostic analysis of network using TRACERT

#### a. Tracert www.google.com

```
C:\WINDOWS\system32>Tracert www.google.com
Tracing route to www.google.com [2404:6800:4007:813::2004]
over a maximum of 30 hops:
                        1 ms 2405:201:e039:d83d:8ea3:99ff:fe4f:7188
      28 ms
               1 ms
 2
                             Request timed out.
                       18 ms 2405:203:400:100:172:31:0:144
      24 ms
              16 ms
                      15 ms 2001:4860:1:1::d10
      24 ms
              18 ms 15 ms 2001:4860:1:1::d10
 6
      19 ms
              16 ms 17 ms 2404:6800:816c::1
 7
      17 ms
              17 ms 23 ms 2001:4860:0:1::1c74
 8
      19 ms
             15 ms 84 ms 2001:4860:0:135f::a
 9
      20 ms
             16 ms
                             2001:4860::12:0:c004
10
      18 ms
              16 ms 16 ms 2001:4860:0:1::48db
      21 ms
              17 ms 18 ms maa03s35-in-x04.1e100.net [2404:6800:4007:813::2004]
```

Tracert is a command for displaying possible routes (paths) and measuring transit delays of packets across an Internet Protocol (IP) network.

Here, the command gives the detailed information given above while tracerouting the given www.google.com and has shown the output and tabulates it.

#### b. Tracert -4 www.google.com

```
C:\WINDOWS\system32>tracert -4 www.google.com
Tracing route to www.google.com [142.250.192.132]
over a maximum of 30 hops:
                       1 ms reliance.reliance [192.168.29.1]
     246 ms
               1 ms
      5 ms
              5 ms
                       3 ms 10.223.40.1
      19 ms 16 ms 18 ms 172.31.0.144
      18 ms 14 ms 14 ms 192.168.68.148
18 ms 19 ms 18 ms 172.26.77.164
      19 ms 15 ms 15 ms 172.26.77.131
      16 ms 15 ms 14 ms 192.168.68.130
      20 ms 18 ms 16 ms 192.168.68.131
      20 ms 18 ms 19 ms 172.31.2.65
      21 ms 17 ms 17 ms 72.14.217.254
30 ms 23 ms 19 ms 108.170.253.105
10
11
12
      42 ms 40 ms 39 ms 108.170.232.242
13
      43 ms 40 ms 40 ms 108.170.248.161
14
      40 ms 39 ms 38 ms 142.250.238.81
      41 ms 43 ms
                       48 ms bom12s18-in-f4.1e100.net [142.250.192.132]
Trace complete.
```

The tracert orders the packets to use IPV4 address to travel from the local computer to the domain and displaying possible routes (paths) and measuring transit delays of packets across an IP.

Task 5: Diagnostic analysis of Domain Name service using NSLOOKUP

## a. nslookup google.com

```
C:\WINDOWS\system32>nslookup google.com
Server: reliance.reliance
Address: 2405:201:e039:d83d::c0a8:1d01

Non-authoritative answer:
Name: google.com
Addresses: 2404:6800:4007:81c::200e
142.250.183.174
```

The nslookup command retrieves the relevant address information directly from the DNS cache of name servers, a process which can be achieved through two different modes that the user can choose from. Here it is google and displays the relevant address information.

b. nslookup -type=soa google.com

This command queries the DNS server for a resource record of a domain and displays it.

#### Task 6: Analyzing Network Statistics using NETSTAT, ARP

#### a. Netstat

```
:\WINDOWS\system32>netstat
Active Connections
 Proto Local Address
                               Foreign Address
                                                       State
                               Asus:54698
        127.0.0.1:1043
                                                       ESTABLISHED
        127.0.0.1:9012
                               Asus:54706
                                                       ESTABLISHED
        127.0.0.1:9487
                               Asus:54703
                                                       ESTABLISHED
        127.0.0.1:54698
                               Asus:1043
                                                       ESTABLISHED
        127.0.0.1:54703
                               Asus: 9487
                                                       ESTABLISHED
       127.0.0.1:54706
                               Asus:9012
                                                       ESTABLISHED
       127.0.0.1:54934
                               Asus: 54935
                                                       ESTABL TSHED
                               Asus: 54934
 TCP
       127.0.0.1:54935
                                                       ESTABL TSHED
        127.0.0.1:54939
                               Asus: 54940
                                                       ESTABLISHED
 TCP
        127.0.0.1:54940
                               Asus:54939
                                                       ESTABLISHED
 TCP
TCP
        192.168.29.223:49542
                               20.198.162.78:https
                                                       ESTABLISHED
                               162.159.133.234:https ESTABLISHED
        192.168.29.223:49762
        192.168.29.223:63413
                               t-bs:https
                                                       TIME_WAIT
        192.168.29.223:63414
                               t-bs:https
                                                       TIME WAIT
        [2405:201:e039:d83d:d5b3:2b29:c6fb:2aeb]:54710 g2600-140f-0400-018b-0000-0000-0000-0057:https CLOSE_WAIT
                                                         g2600-140f-0006-0000-0000-0000-17c7-4309:https CLOSE_WAIT
        [2405:201:e039:d83d:d5b3:2b29:c6fb:2aeb]:63377
        [2405:201:e039:d83d:d5b3:2b29:c6fb:2aeb]:63385
                                                         sd-in-f188:5228
                                                                                ESTABLISHED
        [2405:201:e039:d83d:d5b3:2b29:c6fb:2aeb]:63386
                                                         bom12s15-in-x03:https CLOSE_WAIT
        [2405:201:e039:d83d:d5b3:2b29:c6fb:2aeb]:63394
                                                         bom12s18-in-x0a:https CLOSE WAIT
        [2405:201:e039:d83d:d5b3:2b29:c6fb:2aeb]:63395
                                                         bom12s01-in-x0e:https CLOSE_WAIT
        [2405:201:e039:d83d:d5b3:2b29:c6fb:2aeb]:63403
                                                         [2606:4700::6811:d5cc]:https
                                                                                       ESTABLISHED
                                                         [2606:4700::6812:14bf]:https
[2606:4700::6811:46b0]:https
[2606:4700::6811:eacc]:https
[2606:4700::6811:71b0]:https
        [2405:201:e039:d83d:d5b3:2b29:c6fb:2aeb]:63406
                                                                                        ESTABLISHED
 TCP
        [2405:201:e039:d83d:d5b3:2b29:c6fb:2aeb]:63407
                                                                                        ESTABLISHED
 TCP
        [2405:201:e039:d83d:d5b3:2b29:c6fb:2aeb]:63408
                                                                                        ESTABLISHED
 TCP
        [2405:201:e039:d83d:d5b3:2b29:c6fb:2aeb]:63409
                                                                                        ESTABLISHED
                                                         [2606:4700::6811:cbcc]:https
        [2405:201:e039:d83d:d5b3:2b29:c6fb:2aeb]:63416
                                                                                        ESTABLISHED
        [2405:201:e039:d83d:d5b3:2b29:c6fb:2aeb]:63417
                                                         [2405:201:e039:d83d:d5b3:2b29:c6fb:2aeb]:63418
                                                         [2606:4700:8d72:e7aa:b6c6:308:6813:9a53]:https
                                                                                                          ESTABLISHED
        [2405:201:e039:d83d:d5b3:2b29:c6fb:2aeb]:63420
                                                         bom12s15-in-x03:https TIME_WAIT maa03s28-in-x03:https ESTABLISHED
        [2405:201:e039:d83d:d5b3:2b29:c6fb:2aeb]:63445
        [2405:201:e039:d83d:d5b3:2b29:c6fb:2aeb]:63466
```

The netstat command delivers basic statistics on all network activities and informs users on which ports and addresses the corresponding connections (TCP, UDP) are running and which ports are open for tasks.

#### b. Netstat –o

```
C:\WINDOWS\system32>netstat -o
Active Connections
                                Foreign Address
                                                                        PTD
 Proto Local Address
                                                        State
                                                        ESTABLISHED
         127.0.0.1:1043
                                Asus:54698
                                                                        4152
                                Asus:54706
 TCP
         127.0.0.1:9012
                                                                        16748
                                                        ESTABLESHED
                                Asus:54703
  TCP
        127.0.0.1:9487
                                                       ESTABLISHED
                                                                        22816
                                Asus:1043
  TCP
        127.0.0.1:54698
                                                       ESTABLISHED
                                                                        16748
  TCP
         127.0.0.1:54703
                                Asus:9487
                                                        ESTABLISHED
                                                                        1220
  TCP
         127.0.0.1:54706
                                Asus:9012
                                                        ESTABLISHED
                                                                        1220
 TCP
                                Asus:54935
         127.0.0.1:54934
                                                        ESTABL TSHED
                                                                        2888
  TCP
         127.0.0.1:54935
                                Asus:54934
                                                        ESTABLISHED
                                                                        2888
         127.0.0.1:54939
                                Asus:54940
                                                                        2888
  TCP
                                                        ESTABLISHED
  TCP
         127.0.0.1:54940
                                Asus:54939
                                                        ESTABLISHED
                                                                        2888
         192.168.29.223:49542
                                20.198.162.78:https
                                                        ESTABLISHED
                                                                        5432
```

This command displays information same as netstat along with the process identifier (PID) associated with each displayed connection.

#### c. Arp –a

```
:\WINDOWS\system32>arp -a
Interface: 192.168.42.1 --- 0x7
     Internet Address Physical Address
                                                                                                                                                    Type
     192.168.42.255
                                                                        ff-ff-ff-ff-ff
                                                                                                                                                    static
     224.0.0.22
224.0.0.251
224.0.0.252
                                                                        01-00-5e-00-00-16
                                                                                                                                                    static
                                                                       01-00-5e-00-00-fb
                                                                                                                                                   static
                                                                      01-00-5e-00-00-fc
                                                                                                                                                   static
      239.255.255.250 01-00-5e-7f-ff-fa
                                                                                                                                                   static
Interface: 192.168.29.223 --- 0xd
     Internet Address
192.168.29.1
192.168.29.255
192.168.29.255
224.0.0.22
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.168.29
192.16
                                                                                                                                                   Type
                                                                                                                                                   dynamic
                                                                                                                                                   static
                                                                                                                                                   static
                                                                                                                                                  static
                                                                                                                                                   static
                                                                    01-00-5e-7f-ff-fa
      239.255.255.250
                                                                                                                                                   static
      255.255.255.255
                                                                        ff-ff-ff-ff-ff
                                                                                                                                                    static
Interface: 192.168.157.1 --- 0x11
     Internet Address Physical Address
                                                                                                                                                   Type
     192.168.157.255 ff-ff-ff-ff-ff
224.0.0.22 01-00-5e-00-00-16
224.0.0.251 01-00-5e-00-00-fb
224.0.0.252 01-00-5e-7f-ff-fa
                                                                                                                                                   static
                                                                                                                                                   static
                                                                                                                                                   static
                                                                                                                                                  static
                                                                                                                                                   static
Interface: 192.168.56.1 --- 0x12
      Internet Address Physical Address
                                                                                                                                                   Type
      192.168.56.255
                                                                        ff-ff-ff-ff-ff
                                                                                                                                                   static
      224.0.0.22
                                                                       01-00-5e-00-00-16
                                                                                                                                                   static
      224.0.0.251
224.0.0.252
                                                                        01-00-5e-00-00-fb
                                                                                                                                                    static
                                                                          01-00-5e-00-00-fc
                                                                                                                                                    static
       239.255.255.250
                                                                            01-00-5e-7f-ff-fa
                                                                                                                                                    static
```

The arp command displays the internet to adapter address translation tables used by the address in networking, the -a parameter makes it display all the entries of the ARP table.

## d. arp –a IP Address

The arp command displays the internet to adapter address translation tables used by the address in networking, the -a parameter makes it display all the entries of the ARP table along with its physical address and it's type.